


## TASK: Replace Pull Types on Cordless Shades


Use If/When: Shade has the incorrect pull type or pull is not centered

Tools Needed: N/A

Various pull type options:




1. Remove hem bar end cap. Slide existing pull type from hem bar.



2A. For **hem grip**, slide new hem grip on hem bar.



2B. For **pull rings**, untie rings and tie new rings onto lift cord.



## TASK: Replace Pull Types on Cordless Shades


Use If/When: Shade has the incorrect pull type or pull is not centered

Tools Needed: N/A

**2C.** For **tassels**, untie knot on one of cord and slip off all components (Tassels & Washers). Slide on new components, see next step to tie a figure 8 knot.



**2C continued.** Tie the cord into a figure 8 knot.



**2C continued.** Pull Both ends of cord tight to secure knot.



**3.** Slide metal washer into bottom channel to center of shade, then insert end cap.

